




# Disassembling Insignia Flex 8 Circuit Board

This guide will help you disassemble the internal circuit board and casing.

Written By: Tyler Tyrrell



## INTRODUCTION

This guide should be completed before starting the other guides.


---



### TOOLS:


- [Metal Spudger](#) (1)
  - [Phillips #00 Screwdriver](#) (1)
  - [Plastic Cards](#) (1)
-

## Step 1 — Circuit Board



- ⚠ Turn off the power to your tablet to avoid injury.
- ℹ Position the tablet so that the screen is face down and the power button is located in the upper left hand corner.
- Hold down the power button for five seconds until the tablet powers down.


## Step 2



- Remove the back casing from the screen by sliding a credit card or a similarly thin but firm object in between the casing and the screen.
- ⓘ You may need to use a spudger to initially create separation between the screen and the casing.
- ⓘ Run this object around the perimeter of the tablet until there is separation between the casing and the screen.
- Remove the back casing and set aside.






## Step 3




- Peel tape off of ribbon connectors. Starting at the power button work clockwise around the tablet.

## Step 4




- To remove the camera ribbon cable lift the flap using a spudger.
- Pull the ribbon directly back to release it.

## Step 5



- Remove the second ribbon cable by prying up the black flap using a spudger.
- Pull the ribbon cable horizontally directly away from the battery.



## Step 6



- Remove the final ribbon cable by pulling back the two black tabs on either side of the ribbon cable.
- Pull the ribbon horizontally directly away from the battery.




## Step 7



- Unscrew the 13 screws around the perimeter of the tablet using a ph 00 size screw driver.


**i** These screws are 4.75mm in length.

## Step 8



- Unscrew the four screws and washers using a ph 00 size screwdriver.
  - Set these screws aside in a different pile than the first four.
  - Lift up the circuit board.
- i** These screws are 3.75mm in length. There are plastic washers with each of these screws.


## Step 9



- Unscrew the final two screws that were underneath the circuit board.
- i** These screws are near the charging port and USB adapter.
- i** These screws are also 3.75mm and can be interchanged with the second set of screws only.



## Step 10



- Lift the circuit board and black internal mounting piece away from the screen.
- Set the circuit board aside.

- ⚠ Be careful of the soldered antenna as you separate the pieces.
- ⚠ Be careful of the soldered ribbon that is connected to the power source. This ribbon is fragile.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-22 12:09:27 PM.